



Uzyc WEICONLOCK AN 302-50
Use WEICONLOCK AN 302-50

Mount in the middle of the backrest. If there are additional options, install them in an accessible place.

Montowac w polowie oparcia. Jesli istnieja dodatkowe opcje, montowac w dostepnym miejscu.

Material			
No.	Plan	Article	Quantity
1	YP06496(30)	2732565	1
	YP06497(32)	2732665	1
	YP06498(34)	2732765	1
	YP06476(36)	2731965	1
	YP06477(38)	2731865	1
	YP06478(40)	2731765	1
	YP06479(42)	2732065	1
	YP06480(44)	2732165	1
	YP06481(46)	2732265	1
	YP06482(48)	2732365	1
YP06483(50)	2732465	1	
2	XP02040	2993669	2
3	XP02041	2993670	2
4	M5x10	2991862	2
5	M4x12	2994126	4
6	XP02039	GP14200	2

EP00363 / D

<h1>STABILIZING_BAR</h1>				Plan No.
				EP00363/ D
Scale: 1:2	Drafted	Verified	Confirmed	
Date	19/11/2018	06/07/2020	06/07/2020	
Initials	AS	MK	TK	